










PART 1 - READ ALL INSTRUCTIONS AND SAFETY INFORMATION

- * DO NOT use on any part of the hob including the hob/cooker/oven rings.
- DO NOT use on oven trim, glass oven door, pilot light or heating
- DO NOT use the bag or gloves if they are damaged in any way.
- Gloves must be worn at all times and arms and wrists must always be covered.
- The gloves provided are for convenience only. Long rubber gloves are recommended.

PART 2 - HOW TO TRANSFORM RACK AND GRILLS

- STEP 1**  Ensure you are wearing suitable gloves and your arms and wrists are fully covered at all times.
- STEP 2**  Carefully place no more than two racks into the cleaning bag, taking care not to tear or puncture the bag.
- STEP 3**  Add approximately 1/2 - 3/4 of the cleaning solution.
- STEP 4**  Seal the bag whilst depleting as much air as possible.
- STEP 5**  Fold the bag around the rack(s). Gently tilt the bag until the solution has coated the rack(s).
- STEP 6**  Leave for 2 hours out of the reach of children.
- STEP 7**  After 2 hours, tilt the bag again to re-coat the rack(s) and leave for a further 4 hours. For best results leave overnight.
- STEP 8**  To remove the rack(s). Simply open the bag and pull downwards at the sides. Do not reach inside.
- STEP 9**  Remove the racks(s) and rinse carefully with hot soapy water.

PART 3 - HOW TO TRANSFORM THE INSIDE OF THE OVEN

- STEP 1**  Ensure you are wearing suitable gloves and your arms and wrists are fully covered at all times.
- STEP 2**  Pour some of the remaining solution directly into the centre of the oven.
- STEP 3**  Using a sponge/cloth, carefully apply to the areas to be cleaned working from back to front of the oven.
- STEP 4**  Leave to soak for at least 4 hours or for best results leave overnight.
- STEP 5**  Remove residue with a sponge/cloth working from front to back of the oven.
- STEP 6**  Rinse with plenty of hot soapy water. A second spot application may be needed depending on build up.

PART 4 - DISPOSAL



Partially fill with water, seal and tilt so the solution collects in one bottom corner of the bag, cut off the other corner and then tilt back to allow the residue to be safely poured down the sink.



Simply rinse with water and dispose of in a safe way immediately after use.